



## **INSTRUCTIONS**

### **FIELD APPLIED EXTENSION JAMB INSTALLATION APPLICATION FOR WHEN HORIZONTALLY MULLED WINDOW HEIGHTS EXCEED 84"**

**THE EXTENSION JAMB WILL BE SHIPPED INSTALLED INTO THE EXTENSION JAMB RECEIVER, AND WILL BE CUT AND NOTCHED.**

**STEP A: ATTACH HEADER EXTENSION JAMB AND RECEIVER AS ONE UNIT TO WINDOW MAIN FRAME. FASTEN WITH 3/8" STAINLESS STEEL STAPLES. STAPLES MUST PENETRATE RECEIVER FLANGE AND WINDOW MAIN FRAME. SEE APPLICATION INSTRUCTION (OVER).**

**STEP B: FOR JAMBS AND/OR SILLS – SAME NOTE AS ABOVE APPLIES.**

**NOTE: FOR WINDOW UNITS THAT HAVE FOUR SIDED EXTENSION JAMBS THE SILL EXTENSION JAMB MUST BE ASSEMBLED PRIOR TO JAMB EXTENSION JAMBS.**

**(OVER)**